

Interlocking Astragal Magnetic Spacers

FIRST INSTALL THE ASTRAGAL TO THE DOOR, making sure it is correctly positioned to ensure the L-shaped protector plate does not interfere with the deadlatch.

To install the L-shaped steel protector plate onto the frame face using the interlocking astragal magnetic spacers:

1. Attach the four spacers at equal distances along the length of the plate.
The magnets will hold them in place.
2. Place the steel protector plate onto the frame and close the astragal over the plate and spacers.
3. Move the plate up or down to set the correct height.
4. Run a self-tapping sheet metal screw through the pre-drilled holes at the top and bottom of the plate.
5. Before opening the door, drill a hole and install a screw at the approximate centre line between the top and bottom of the plate. This will secure the correct position of plates that may be warped.
6. Open the door and remove the magnetic spacers.
7. Test the door to make sure it operates correctly and secure the plate onto the frame using heavy duty rivets as suggested by the manufacturer.