

Precision Paddle Fit 20

The Precision Paddle Fit 20 is designed to quickly and accurately mark the mounting holes for the Adams Rite push paddle. It is faster than measuring the hole locations from the centre line and more effective than using the paddle body as a template.

The small metal blade on the end of the jig removes the micro e-clip from the cam disc to facilitate changing the hand, if required. Larger e-clips can be removed with a small-bladed screw driver.

E-Clip Removal Instructions

1. Rotate the e-clip so the open end faces the top of the cam disc.
2. Position the stainless steel blade against the e-clip ends.
3. Cover the cam pivot post and e-clip with your thumb to keep the e-clip from getting lost.
4. Push the steel blade against the e-clip to remove it from the post.

Paddle Marker Jig Instructions

1. Once the cam disc has been installed and locked down with the set screw, position the marker jig by placing it on the two posts on the back of the cam disc.
1. Make sure the jig runs parallel with the door edge. You may need to loosen the set screw slightly to make sure the jig is perfectly parallel to the door edge.
2. Use the supplied transfer punch to mark the top and bottom holes.
3. Remove the jig and drill the appropriate sized holes, depending on the model of push paddle you are using.